

Ikegami®

Ten 2.5" LCD Monitors in 3 RU

V-R25P



The V-R25P is a rack mountable unit that has ten 2.5" active matrix LCD panels with loophrough capability. These 2.5" panels have 480 × 234 pixels making them a true high resolution LCD panel. This unit also has a unique feature that allows the unit to tilt up or down for optimum viewing angle. The unit fits into an EIA standard 19" rack, three rack spaces high. Each of the ten screens has auto-signal recognition and auto NTSC/PAL recognition. If there is no video signal going to the screen, a blue screen will appear. Unit is turned on and off by using the small toggle switch located on the side of the unit and is accessed by tilting the unit down. Unit comes complete with power supply, instructions and dry erase marker for labeling screens.

■ SPECIFICATIONS:

Viewing Area:	1.97" (H) x 1.48" (V)	Video Input:	10 X Composite NTSC / PAL
Aspect Ratio:	4 : 3		
Pixels:	480 (H) x 234 (V)		
Dot Pitch:	0.11mm x 0.16mm		
Display:	2.5" Active Matrix LCD	Dimensions:	Width 19.125 Inch
Brightness:	250 cd		Height 5.14 Inch
Power Requirement:	12 VDC, 3 Amp.		Depth 2.65 Inch

Design and specifications are subject to change without notice.

0502JTLr1

Ikegami Ikegami Electronics (U. S. A.) Inc.

■ URL <http://www.ikegami.com>

Headquarters	37 Brook Avenue, Maywood, New Jersey 07607 Phone 201-368-9171 Fax 201-569-1626
West Coast Office	2631 Manhattan Beach Blvd., Redondo Beach, CA 90278 Phone 310-297-1900 Fax 310-536-9550
Southwest Office	526 Bluebird Lane, Red Oak, TX 75154 Phone 972-869-2363 Fax 972-556-1057
Midwest Office	747 Church Road, Unit C1, Elmhurst, IL 60126 Phone 630-834-9774 Fax 630-834-8689
Southeast Office	5200 N.W. 33rd Ave. Suite 111, Ft. Lauderdale, FL 33309 Phone 954-735-2203 Fax 954-735-2227